



NOYES® M and C-Series Software Installation Instructions

How to Create the Installer USB Key

- Locate the desired Updater Software from www.AFLglobal.com/go/Software
- Execute the Updater by double clicking on the filename - 'Updater.exe'.
- Click 'Run' and the following screen will appear:



- Click the OK button.
- The following Screen will appear:




continued on next page ->


NOYES®

M and C-Series Software Installation Instructions

- Put USB key into USB slot on the computer.
- Click the "Browse" button and select the drive where you inserted the USB key.



- Click the "OK" Button.
- Click the "Unzip" Button.




continued on next page ->


NOYES®

M and C-Series Software Installation Instructions

- Files will now extract to the USB Key.



- The following screen will appear when done. (NOTE: the number of file(s) will depend on which Updater you are installing.)



- Click the "OK" button.
- Click the "Close" button.
- The 'Installer' USB key is ready for software installation.


continued on next page ->

NOYES®


M and C-Series Software Installation Instructions

Software Installation Instructions

- Insert the USB drive into USB Host port of the device that being upgraded. At the welcome screen press 'Next' to continue.



- Updater will start running and display the Overall Progress.
- **Note:** The unit will reboot several times during the upgrade process. Do not remove the USB drive until prompted to do so.
- Updater will run until completion and display the following message:



- When prompted, please remove the USB drive.



- Your unit will restart one more time to initialize the upgrade.
- When complete, the Main Menu will be displayed.