

# 455

45S Standard Kit



45S on Tripod

# **Fujikura 45S Fusion Splicer**

The 45S cladding alignment fusion splicer is changing the way people splice fibre in small to mid-fibre count applications. This Fujikura splicer debuts a landmark improvement to the fusion splicing process with the ability to prepare and load both fibres simultaneously. The hand-held fibre coating stripper, the SS-05, is capable of stripping two 250 µm coated fibres in the same pass, along with the CT-16A cleaver adapter plate which can likewise accommodate two bare fibres for cleaving. After preparation, the 45S patented sheath clamps enable loading both fibres simultaneously into the splicer with one fibre in each hand. The user can press down on the sheath clamp base to close it while positioning the fibre in the v-grooves. This enables one-handed operation.

Furthermore, the 45S sheath clamps are mechanically linked to the wind protector, so after splicing is finished, opening the wind protector also opens both sheath clamps for quick sleeve positioning and transfer to the tube heater. The 45S tube heater shrinks sleeves much faster than its predecessor with a nominal  $\sim$ 20 second heat time for 60 mm sleeves down from  $\sim$ 26 seconds. The simultaneous fibre preparation capability, automated sheath clamp opening, and a faster tube heater, combine to lower the overall fusion splicing cycle time by  $\sim$ 30% or more.

The 45S continues to benefit the user experience with improvements to fibre placement, battery access, and machine ergonomics. Previously, when using sheath clamps, if the cleaved fibre was accidentally set past the electrode centerline, the machine would send an error and require manual intervention. The 45S will now accept this mistake and reverse the fibre to correct position automatically. With a cube form factor, the 45S is easily transported and operated in space-constrained environments. The adjustable screen can alleviate glare from the sun and adjust with abnormal splicer positions confronted in challenging splice locations.

Backed by the best service team in the industry, the Fujikura 45S is the ideal splicer to use when portability, ruggedness, speed, and reliability are needed. If you'd like to see the 45S capabilities first-hand, please contact us at 1300 232 476 to arrange a product demonstration at your earliest convenience.

### **Applications**

- 5G Small Cell Site
- FTTx drops and terminations
- MDF/IDF splices and terminations
- Rural fibre deployments and restorations

### **Features**

- Simultaneous fibre preparation with newly patented sheath clamp design
- Sheath clamps automatically opened with the wind protector
- Automatic fibre placement correction
- Active Fusion Control for arc optimisation with every splice
- Active Blade Management for cleave quality monitoring and correction
- Easy-access battery, screen position adjustments, and ergonomic adaptations
- Fully ruggedized for shock, moisture and dust resistance



# **Fujikura 45S Fusion Splicer**

### **Features**







Sleeve Positioning



Work Tray with Neck Strap



CT-16A Adapter Plate on CT-50



- 1 For 2.3 mm
- 2 For 900 μm
- ③ For 250 μm
- 4 For 250 μm

Fibre stripper SS-05

## **Ordering Information**

DESCRIPTION	AFL NO.	
Fujikura 45S Standard Kit	FUJ45S-CT50	
Includes: CT-50 cleaver, SS-05 single fibre stripper, 1 pair each FH-70-250 and FH-70-900 fibre holders, SP-04 set plates, ELCT2-16B Spare Electrodes		
(Pair), ADC-21 AC Adapter, BTR-17 Battery Pack (installed), ACC-09 Power Cord, USB-01 USB Cable, AP-02 Alcohol Container, WT-10 work tray,		
ST-03 carrying case strap, TS-03 tripod screw, CC-45 Transit Case, 1 year factory warranty, and instruction manual downloaded from splicer		
Fujikura 45S Kit without Cleaver		
Includes: SS-05 single fibre stripper, 1 pair each FH-70-250 and FH-70-900 fibre holders, SP-04 set plates, ELCT2-16B Spare Electrodes (Pair),		
ADC-21 AC Adapter, BTR-17 Battery Pack (installed), ACC-09 Power Cord, USB-01 USB Cable, AP-02 Alcohol Container, WT-10 work tray,		
ST-03 carrying case strap, TS-03 tripod screw, CC-45 Transit Case, 1 year factory warranty, and instruction manual downloaded from splicer		

## **Recommended Accessories**

DESCRIPTION	AFL NO.	
Cleavers AND Strippers		
CT-50 Fibre Cleaver	S017030	
CT-16 Fibre Cleaver	S018330	
SS-05 Dual Fibre Stripper	S018327	
Fibre Holders		
CLAMP-S35B Loose Buffer Sheath Clamp	S018333	
FH-70-250 (250 μm single fiber)	S017111	
FH-70-200 (200 μm single fiber)	S017711	
FH-70-900 Fibre Holders (900 µm single fibre)	S017113	
FH-60-LT900 (900 µm loose buffer tube)		
FUSEConnect® Accessories		
FH-FC-20 (900 µm within 2.0 mm sheathing) (each)	S014696	
FH-FC-30 (900 µm within 3.0 mm sheathing) (pair)	S014695	
FH-FC-900 (900 μm cable) (each)	S014697	
CLAMP-FC-2000 (pair)	S014705	
CLAMP-FC-3000 (pair)	S014704	

DESCRIPTION	AFL NO.
Power Supply Options	
BTR-17 Battery Pack	S018324
ADC-21 AC Adapter	S018168
ACC-09 Power Cord	S014390
Miscellaneous	
WT-10 Work Tray	S018336
TS-03 Tripod Screw	S017524
ST-03 Carrying Case and Work Tray Strap	S017549
CLAMP-DC-12 drop cable clamp on work tray	S017550
ELCT2-16B Electrodes	S017103
CC-45 Transit Case	S018326
Splicer V-Groove Cleaning Kit	S014397
USB-01 USB Cable	S014777
SP-04 Fibre Holder Set Plates	S018332
AD-16A Adapter Plate (CT-50 and CT-16 up to 900 µm)	S018328
Portable Tripod Workstation (see web listing for more detail)	S014773



# **Fujikura 45S Fusion Splicer**

## **Specifications**

PARAMETER		VALUE
Fibre alignment method		Active cladding alignment
Fibre count can be spliced		Single fiber
		Single-mode optical fibre
Applicable fibre	Fibre type	Multimode optical fibre
	Cladding dia.	Approx. 125 µm
		Coating diameter: Max. 3,000 µm
	Sheath Clamp	Cleave length: 5 to 16 mm *1
Applicable coating	Fibre Holder	Coating diameter: 160 µm – 3,000 µm based on available fibre holder options
		Cleave length: Approx. 10 mm
	Splice loss*2	ITU-T G.652: Avg. 0.03dB
		ITU-T G.651: Avg. 0.01dB
		ITU-T G.653: Avg. 0.05dB
Fiber splice performance	Sprice 1033	ITU-T G.655: Avg. 0.05dB
Tibel spilee performance		ITU-T G.657: Avg. 0.03dB
		SM FAST mode: Avg. 6 to 8 sec.
	Splicing time *3	SM AUTO mode: Avg. 8 to 11 sec.
	Sleeve type	Heat shrinkable sleeve
Applicable protection sleeve	Sleeve length	Max. 66 mm
Applicable protection sieeve	Sleeve dia.	Max. 6.0 mm before shrinking
		60 mm mode: Avg. 21 to 23 sec.
Sleeve heat performance	Heat time *4	60 mm slim mode: Avg. 16 to 18 sec.
Fibre tensile test force		
		Approx. 2.0 N Approx. 6,000 splices
Electrode life *5		
	Dimensions W	Approx.131 mm without projection
Physical description	Dimensions D	Approx.123 mm without projection
·	Dimensions H	Approx.121 mm without projection
	Weight	Approx. 1.4 kg including battery
	Temperature Humidity	Operate : -10 to 50°C
e 1 1 100		Storage : -40 to 80°C
Environmental condition		Operate : 0 to 95% non-condensing
		Storage : 0 to 95% non-condensing
	Altitude	Max. 5,000 m
AC adaptor	Input	AC100 to 240V, 50/60Hz, Max. 1A
	Output	Approx. DC 19V, Max. 2.1A
	Type	Rechargeable Lithium Ion
	Output	Approx. DC14.4V / 3,190mAh
	Capacity *6	60 mm heat mode: Approx. 200 splice & heat cycles
		60 mm slim heat mode: Approx. 230 splice & heat cycles
Battery pack		Operate: -10 to 50°C
	Temperature	Recharge : 0 to 40°C
	,	Short term storage of 30 days: -20 to 50°C
		Long term storage: -20 to 30°C
	Battery life *7	Approx. 500 recharge cycles
Display	LCD monitor	TFT 4.95 inches with touch screen
	Magnification	Approx. 132 to 300X
Illumination	V-grooves	LED lamp
Interface	PC	USB2.0 MINI B type
	External LED lamp	USB 2.0 A type
		Approx. DC5V, 500mA
	Wireless *8	Bluetooth® 5.2



# **Fujikura 45S Fusion Splicer**

### **Specifications**

PARAMETER		VALUE
Data storage	Splice mode	100 splice modes
	Heat mode	30 heat modes
	Splice result	20,000 splices
	Fiber image	100 images
Screw hole for tripod		1/4-20UNC
Other features		Fusion control
	Automatic functions	Blade management and control
		Splice start
		Heater start
	Reference guide	PDF file stored on splicer
	Sheath clamp	Open with/without wind protector
		Close when setting fibre
		Easy sleeve positioning design
	Electrode	Tool-less replacement
	PC Software	Splicer firmware update via internet
		Parameter Upload and download

### NOTES:

- \*1 Cleave length range depending on fibre type
  - 5-16 mm: 125  $\mu m$  cladding dia. And 250  $\mu m$  coating dia.
  - 10 16 mm: 125 µm cladding dia. And 400 or 900 µm coating dia.
- \*2 Measured with cut-back method relevant to ITU-T and IEC standard after splicing Fujikura identical fibres. The average splice loss changes depending on the environmental condition and fibre characteristics.
- \*3 Measured at room temperature. The definition of splice time is from the fibre image appearing on the LCD monitor to the estimated splice loss. The average splice time changes depending on the environmental conditions, fibre type, and fibre characteristics.
- \*4 Measured at room temperature with the AC adapter. The heat time is defined from the start beep sound to the finish beep sound. The average heat time changes depending on the environmental conditions, sleeve type, and battery pack condition. In addition, since the heating operation is constantly optimized, the average heating time changes depending on the usage conditions of the fusion splicer.
- \*5 The electrode life changes depending on the environmental conditions, fibre type, and splice modes used.
- \*6 Test Conditions
  - Splice and heat time: 1 minute cycle
  - Using the splicer power save settings, subject to our testing condition
  - Using a new battery
  - Room temperature
  - The battery capacity changes when testing in different conditions than above
- \*7 The battery capacity decreases to half after approx. 500 discharge and recharge cycles. The battery life is shortened further when using outside of the storage and operating temperature ranges, or if completely discharged when stored for an extended period without recharging.
- \*8 Bluetooth mark and logos are registered trademarks of Bluetooth SIG, Inc.